

# MAXIMUM VERSATILITY ON EVERY JOBSITE.

PNEUMATIC TIRED ROLLER, BW 11 RH-5



# CONTINUING THE TRADITION OF EXCELLENCE.

The BW11RH-5 pneumatic tired roller is one of the most versatile machine in the BOMAG line.

This roller achieves its high compaction performance through the combined effect of the vertical pressure with horizontal forces directed to all sides under each of the nine, overlapping tires.

## LESS SERVICE & MAINTENANCE:

- Wide-opening engine hood allows easy access for servicing
- Maintenance and check points are accessible from ground level
- Heavy duty long-life articulating joint
- Maintenance free - no grease points
- Maintenance free SAHR (Spring Applied Hydraulic Released) brakes







## MAXIMUM PROTECTION AND CLEAR VISIBILITY

- ROPS/FOPS with seatbelt or cab
- Centrally located steering wheel and dashboard
- Centered swivelling seat

## THREE SPEED HYDROSTATIC TRANSMISSION:

- Maximum gradeability in low range
- Optimum performance in medium or work range
- Top production in high range

## FUNCTIONAL FRAME DESIGN.

Strategically placed ballast compartments provide:

- Lower center of gravity
- Exceptional stability
- Uniform weight distribution

## BALANCED WHEEL LOADS AND UNIFORM COMPACTION

The centerpoint articulated steering (35° articulation and 10° oscillation) for optimum compaction on tight turns and also produces a narrow turning radius (3.1 m / 10.2 ft).

Head Office / Hauptsitz:

**BOMAG**

Hellerwald  
56154 Boppard  
GERMANY  
Tel. +49 6742 100-0  
Fax +49 6742 3090  
info@bomag.com

**BOMAG Maschinen-  
handels-gesellschaft m.b.H.**

Porschestraße 9  
1230 Wien  
AUSTRIA  
Tel. +43 1 69040-0  
Fax +43 1 69040-20  
austria@bomag.com

**BOMAG MARINI EQUIPAMENTOS LTDA.**

Rua Comendador Clemente Cifali, 530  
Distrito Industrial Ritter  
Cachoeirinha – RS  
BRAZIL  
ZIP code 94935-225  
Tel. +55 51 2125-6677  
Fax +55 51 3470-6220  
brasil@bomag.com

**BOMAG (CANADA), INC.**

3455 Semenyk Court  
Mississauga, Ontario L5C 4P9  
CANADA  
Tel. +1 905 361 9961  
Fax +1 905 361 9962  
canada@bomag.com

**BOMAG (CHINA)**

Compaction Machinery Co. Ltd.  
No. 2808 West Huancheng Road  
Shanghai Comprehensive  
Industrial Zone (Fengxian)  
Shanghai 201401  
CHINA  
Tel. +86 21 33655566  
Fax +86 21 33655508  
china@bomag.com

**BOMA Equipment**

**Hong Kong LTD**

Room 1003, 10/F Cham Centre  
700, Castle Peak Road  
Kowloon  
HONG KONG  
Tel. +852 2721 6363  
Fax +852 2721 3212  
bomahk@bomag.com

**BOMAG France S.A.S.**

2, avenue du Général de Gaulle  
91170 Viry-Châtillon  
FRANCE  
Tel. +33 1 69578600  
Fax +33 1 69962660  
france@bomag.com

**BOMAG (GREAT BRITAIN), LTD.**

Sheldon Way  
Larkfield, Aylesford  
Kent ME20 6SE  
GREAT BRITAIN  
Tel. +44 1622 716611  
Fax +44 1622 710233  
gb@bomag.com

**BOMAG Italia Srl.**

Via Roma 50  
48011 Alfonsine  
ITALY  
Tel. +39 0544 864235  
Fax +39 0544-864367  
italy@bomag.com

**FAYAT BOMAG Polska Sp. z o.o.**

Ul. Szyszkowa 52  
02-285 Warszawa  
POLAND  
Tel. +48 22 482 04 00  
Fax +48 22 482 04 01  
poland@bomag.com

**FAYAT BOMAG RUS OOO**

141400, RF, Moscow region  
Khimki, Klayazma block, h. 1-g  
RUSSIA  
Tel. +7 (495) 287 92 90  
Fax +7 (495) 287 92 91  
russia@bomag.com

**BOMAG GmbH**

300 Beach Road  
The Concourse, #18-06  
Singapore 199555  
SINGAPORE  
Tel. +65 6 294 1277  
Fax +65 6 294 1377  
singapore@bomag.com

**BOMAG Americas, Inc.**

125 Blue Granite Parkway  
Ridgeway SC 29130  
U.S.A.  
Tel. +1 803 3370700  
Fax +1 803 3370800  
usa@bomag.com